

Line Pressure PSI

| | | 100 | 150 | 200 | 250 | 500 | 750 | 1000 |
|------|-------------|------|------|------|------|------|------|------|
| | CODE | 0100 | 0150 | 0200 | 0250 | 0500 | 0750 | 1000 |
| 20 | 0020 | x | | | | | | |
| 25 | 0025 | x | | | | | | |
| 30 | 0030 | x | x | | | | | |
| 50 | 0050 | x | x | x | | | | |
| 75 | 0075 | x | x | x | x | | | |
| 100 | 0100 | x | x | x | x | x | | |
| 150 | 0150 | | x | x | x | x | x | |
| 200 | 0200 | | | x | x | x | x | x |
| 250 | 0250 | | | | x | x | x | x |
| 300 | 0300 | | | | | x | x | x |
| 400 | 0400 | | | | | x | x | x |
| 500 | 0500 | | | | | x | x | x |
| 750 | 0750 | | | | | | x | x |
| 1000 | 1000 | | | | | | | x |

“x” denotes differential pressure range available.

Bar and kg/cm² available; consult factory for ordering assistance.